

# INSTALLING DS-600 SINGLE HAND CONTROL RADIO INTO THE LAKE REAPER BAIT BOAT

## STEP 1 - PLUGGING INTO RECEIVER



BROWN (NEGATIVE) - RED (POSTIVE) - ORANGE (SIGNAL)

WIRE/PLUG USED FOR THE STEERING FUNCTION (USALLY LABELLED 111)

WIRE/PLUG USED FOR THE HOPPER RELEASE FUNCTION (USALLY LABELLED 444)



BLACK (NEGATIVE) - RED (POSTIVE) - WHITE (SIGNAL)

WIRE/PLUG USED FOR THE FORWARD-REVERSE FUNCTION (USALLY LABELLED 222)



- PLUG WIRE '111' INTO CHANNEL 1 (BROWN - RED - ORANGE WIRE)

- PLUG WIRE '222' INTO CHANNEL 2 (BLACK - RED - WHITE WIRE)

- PLUG WIRE '444' INTO CHANNEL 5 (BROWN - RED - ORANGE WIRE)

## STEP 2 - REVERSING THE STEERING FUNCTION

Hold down number 5 button and turn on handset.

Once handset is on, release the 5 button and you will then see the red handset light flashing with 2 green lights either side. Now move the joystick to the left (9 o'clock)

And you will hear a double beep and the red light will now be solid and the green lights will disappear.

Reverse set-up is now completed.

INSTALLATION IS NOW COMPLETE.