

INSTALLING DS-600 SINGLE HAND CONTROL RADIO INTO THE LAKE REAPER BAIT BOAT

STEP 1 - PLUGGING INTO RECEIVER



BROWN (NEGATIVE) - RED (POSTIVE) - ORANGE (SIGNAL)

WIRE/PLUG USED FOR THE STEERING FUNCTION (USALLY LABELLED 111)

WIRE/PLUG USED FOR THE HOPPER RELEASE FUNCTION (USUALLY LABELLED 444)



BLACK (NEGATIVE) - RED (POSTIVE) - WHITE (SIGNAL)

WIRE/PLUG USED FOR THE FORWARD-REVERSE FUNCTION (USALLY LABELLED 222)



- PLUG WIRE '111' INTO CHANNEL 1 (BROWN - RED - ORANGE WIRE)

- PLUG WIRE '222' INTO CHANNEL 2 (BLACK - RED - WHITE WIRE)

- PLUG WIRE '444' INTO CHANNEL 4 (BROWN - RED - ORANGE WIRE)

---NEGATIVE
---POSTIVE
---SIGNAL

STEP 2 - REVERSING THE STEERING FUNCTION

- PRESS DOWN THE NUMBER 4 BUTTON ON THE HANDSET AND WHILST PRESSING DOWN TURN THE HANDSET ON (THERE WILL BE VERY FAST TRIPLE BEEP NOISE AFTER THE START UP TONE)

- ONCE YOU HEAR THIS NOISE. MOVE THE JOYSTICK TO THE LEFT HAND SIDE (9 O'CLOCK) AND HOLD UNTIL YOU HEAR A 'BEEP' NOISE.

- REVERSING IS NOW COMPLETE.

INSTALLATION IS NOW COMPLETE.